

ADS-B receiver

User manual

Version 1.00



LXNAV d.o.o. • Kidričeva 24, 3000 Celje, Slovenia • tel +386 592 33 400 fax +386 599 33 522
info@lxnav.com • www.lxnav.com

1	Important Notices	3
1.1	Limited Warranty	3
	Packing Lists	4
2	Technical Data	5
2.1	Power and Consumption	5
2.2	Size and Weight	5
3	System description	6
3.1	Switching on the Unit	6
3.2	Normal operation	6
3.3	How the system works	6
4	Installation	7
5	Wiring	8
5.1	ADSB receiver PORT1 and PORT2 pinout (RJ45)	8
5.1.1	ADSB receiver RF connector side description	8
5.1.2	Installation examples	9
5.1.2.1	LXxxxx Flarm - ADSB	9
5.1.2.2	Flarm - ADSB - FlarmView	9
5.1.2.3	Flarm - ADSB - FlarmLED	10
6	Firmware Update	11
7	Revision History	12

1 Important Notices

Information in this document is subject to change without notice. LXNAV reserves the right to change or improve their products and to make changes in the content of this material without obligation to notify any person or organization of such changes or improvements.



A Yellow triangle is shown for parts of the manual which should be read very carefully and are important for operating the ADSB receiver.



Notes with a red triangle describe procedures which are critical and may result in loss of data or any other critical situation.



A bulb icon is shown when a useful hint is provided to the reader.

1.1 Limited Warranty

This RPM flap product is warranted to be free from defects in materials or workmanship for two years from the date of purchase. Within this period, LXNAV will, at its sole option, repair or replace any components that fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts and labour, provided that the customer pays for shipping costs. This warranty does not cover failures due to abuse, misuse, accident, or unauthorized alterations or repairs.

THE WARRANTIES AND REMEDIES CONTAINED HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED OR STATUTORY, INCLUDING ANY LIABILITY ARISING UNDER ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, STATUTORY OR OTHERWISE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE.

IN NO EVENT SHALL LXNAV BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM THE USE, MISUSE, OR INABILITY TO USE THIS PRODUCT OR FROM DEFECTS IN THE PRODUCT.

Some states do not allow the exclusion of incidental or consequential damages, so the above limitations may not apply to you. LXNAV retains the exclusive right to repair or replace the unit or software, or to offer a full refund of the purchase price, at its sole discretion. SUCH REMEDY SHALL BE YOUR SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY.

To obtain warranty service, contact your local LXNAV dealer or contact LXNAV directly.

Packing Lists

- ADSB receiver
- 1x FLARMVIEWPF-CA
- 1x ADSB antenna

2 Technical Data

2.1 Power and Consumption

Table 1: Absolute maximum ratings

Parameter	Symbol	Rating	Units
Power Supply	Power	36.0	V
Power Consumption	I_1	85	mA

Table 2: Electrical characteristics

Parameter	Symbol	Min	Typ	Max	Units
Power Supply	Power	8.0	12.0	36.0	V

2.2 Size and Weight

Size: 55mm x 90mm x 25mm

Weight: 160g

3 System description

3.1 Switching on the Unit

ADSB receiver is switched on automatically, when it gets enough power supply from either PORT In or PORT OUT RJ45 connector.

3.2 Normal operation

ADSB receiver goes into normal operating mode, when it receives signals from enough GPS satellites.

3.3 How the system works

ADSB receiver can listen on 10990MHz transponder data Mode S and ES. Received data will be transmitted to the output port in Flarm standard NMEA format.

ADSB receiver will operating only if we feed it with gps data to input port. GPS data must be standard NMEA format. ADSB receiver will automatically detect baudrate on input port and transmit NMEA data on output port at the same baudrate.

4 Installation

ADSB receiver has typically connected to the input port a GPS source. This is normally flarm device with NMEA output or classic GPS with standard NMEA output.




At the other side is SMA connector for ADSB antenna. Red LED indicates receiving ADSB traffic.



5 Wiring

5.1 ADSB receiver PORT1 and PORT2 pinout (RJ45)



Pin number	Description
1	+ Power input
2	+ Power input
3	n.c.
4	Ground
5	Data output (TX)
6	Data input (RX)
7	- Power input
8	- Power input




Underneath each port there are TX (transmit-green) and RX (receive-red) status LEDs that flash when that port is receiving or transmitting data.

5.1.1 ADSB receiver RF connector side description

In the line with ADSB antenna SMA connector is red LED, which blinks, when ADSB traffic is present.

5.1.2 Installation examples

5.1.2.1 ADSB – LX80xx/Lx90xx




On the main display unit go to the setup menu and choose the Hardware->Flarm menu item. Change mode to Ext. (PC).




If you wish to connect additionally flarm display, you must use flarm splitter on ADS-B output.

5.1.2.2 Flarm - ADSB - FlarmView



5.1.2.3 Flarm - ADSB - FlarmLED



6 Firmware Update

Firmware can be updated via special “**flarm update cable**”, connected to PC through serial interface.

You can get flash loader at: <https://gliding.lxnav.com/lxdownloads/firmware/> (S7 PC update tool)

For the update you need file named `_x*.lxfw` (x= version nr.) on your computer.

Update procedure:

- Connect ADSB receiver FW update port (OUT) to the update cable to PC and power supply
- On Tool select communication port to which your ADSB receiver is connected to
- Select baudrate 57600
- Select .lxfw file
- Press Flash
- Apply power to ADSB receiver



To update ADSB receiver, a Flarm update cable with 12V DC and a COM port on PC is required.



7 Revision History

May 2022	Rev0	Initial release version 1.00
March 2023	Rev1	Added chapter 5.1.2.1